



Air Vent Dash Mount Instructions - Ver 1.2

Call 888-722-5240 with any question about installation during the hours of 8am to 5pm Monday - Friday, Pacific Time

Step 1: After removing the components from the package/carton, you will assemble the two main pieces. On the attachment bracket there is one rectangular hook that inserts into the matching hole in the device mounting bracket. Slide this firmly into place. **NOTE: A small 3rd piece (adapter) is included so that it may connect to other CommuteMate Mounts and Holders.**

Step 2: There is a top/bottom to the device mount. The silver hook that attaches on the inside of the air vent is the top and the black curved support base is at the bottom resting against the bottom of the air vent.

Step 3: Locate which air vent is most suitable for the mount. Place your thumb on the round cylinder and depress the spring-loaded clip while inserting the metal hook into the vent and slide it over the vent blade. Let the spring loaded clip lock the metal hook onto the vent blade and your Mount is now in place.

Step 4: The mount, designed for a smartphone or GPS, is fully adjustable. The small rectangular button on the lower left can be depressed to allow the ratcheting, padded braces to retract. You can squeeze these together when you install your device where the pads actually grip the unit in place.

Step 5: There is a lower (flip-down) bracket that can easily be flipped into position pressing the lower corners (either) with your thumb. The bracket flips out and provides a stationary stand for whatever device you wish to support.

Step 6: Adjusting the mount vertically or horizontally: Simply rotate the device (90 degrees) to get your desired position.

Step 7: To remove the entire mount from the dashboard, place your thumb on the round cylinder, reach your finger to pull the spring-loaded clip off of the vent blade, push the mount towards the front of the vehicle slightly and lift the metal hook up and out of the air vent.

Warnings:

- **Do not make adjustments to your device or this mount while you are driving.**
- **Do not let this mount or your device block your view in any way.**
- **Make sure the device is secure before driving by tightening the adjuster firmly.**

<http://www.heininger.biz>

Bellingham, Washington 98229 USA

Limited Liability, 90 Day Warranty Policy

Heininger Holdings, LLC, warrants the original owner of each new CommuteMate product against defects in workmanship and materials for 90 Day from the date of purchase (at retail) of the product, provided it is purchased from an authorized CommuteMate product dealer. This Limited 90 Day Warranty is not transferable and shall only apply to normal and ordinary use, for which the product was intended, as described in the Instructions provided.

Warranty claims are to be made directly to Heininger Holdings and must be accompanied by a sales receipt or other appropriate proof-of-purchase document. Should this product or any part or accessory be determined by Heininger Holdings, to be defective and covered by this Limited 90 Day Warranty, it will be repaired or replaced at the option of Heininger Holdings, without further charge. The cost of transportation to and from the referred warranty inspection facility for repair or replacement of any defective part and/or accessory and any related charges is not covered by this warranty, and is to be paid by the owner.

The warranty does not cover normal wear and tear, worn and normal use cosmetic blemishes, improper assembly, lack of maintenance, or custom alteration/installation of any parts or accessories not originally intended or compatible with the product as sold. The warranty does not apply to damage or failure resulting from an accident, abuse or neglect.

This warranty is given in lieu of all other expressed warranties, implied warranties, including without limitation implied warranties of merchandising ability and fitness for a particular purpose, and are limited to the duration and specification of this warranty. In no event shall Heininger Holdings, be liable for damages in excess of the purchase price of the CommuteMate product, for any loss of use, loss of time, inconvenience, commercial loss, lost profits or savings or any incidental, special, consequential, direct or indirect damages arising out of the use or inability to use such product, to the full extent as such may be disclaimed by the law. Labor charges for part changeover are not covered by this warranty.